

Adrenaclick Auto-Injector Belt Pack

**Cut out both pattern pieces and
tape together. Pattern should be
19" long by 5" wide.**

You will need:

Rip-stop Nylon or Other Sturdy Fabric.

Interfacing

Matching Thread

2" wide velcro

Strap Webbing

**Pin pattern to fabric and cut out two
pieces. Cut one pattern piece out of
interfacing. Iron or sew the interfacing to
one of the fabric pieces.**

**Pin the fabric pieces together with the
interfacing side facing up.**

**Sew together but leave the
bottom edge open.**

**Turn the pack inside out and
iron all the seams so they lay flat.**

**Turn the hem around the unsewn edge at
the bottom and tuck it inside the pack.**

**Pattern
Piece
One**

RachelArmington.com