

Pattern Piece Two

Tape to Piece One Here

Iron that edge flat and sew over the hem.

Now all sides of the pack have been sewn.

Next you need to sew the velcro closure onto the flap and the front of the pack.

Iron that edge flat and sew over the hem.

Now all sides of the pack have been sewn.

Next you need to sew the velcro closure onto the flap and the front of the pack.

Sew a 2" by 2" square of velcro onto the inside of the flap.

Position where the facing piece of velcro should go on the front of the pouch.

Position two straps on what will be the back of the pouch and sew into place.

Fold the pouch outside in, so that the straps and what will be the front of the pouch are facing each other.

Pin along each side.

Sew up one side of the pouch, then back down.

Sew the other side of the pouch the same way.

Tie off any thread ends.

Turn the pouch inside out, slip your auto injectors inside, and slide your belt through the straps on the back of the pouch.

You can see photos at

RachelArmington.com